

## Clean and Strip



### 1 Product Description

Special cleaning agent for cleaning and stripping newly installed or heavily soiled vinyl, linoleum and rubber floors. Removes the remains of old care products, stubborn and adhesive residue.

- Universal Floor Cleaner for all elastic floorings
- removes even the most stubborn dirt from care products to adhesive residues
- No labelling according to CLP regulation
- NTA-free

### 2 AREAS OF APPLICATION

Vinyl, linoleum and rubber flooring. Gentle with low PH value, therefore particularly suitable for linoleum and rubber flooring.

Please pay attention to our technical instructions specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com)

### 3 METHOD OF APPLICATION

Cleaning after installation: Remove coarse dirt with a sweeping brush or vacuum cleaner. Dilute Clean and Strip with water in a ratio of between 1:5 and 1:10. In case of particularly stubborn residues (e.g., in the commercial sector) use undiluted if required. For low levels of dirt adjust the strength of the solution as appropriate. Apply the cleaning solution to the floor area, distribute and allow to stand for approx. 10 minutes. Clean the floor surface using a scrubber, Padmaster System or Monodisc SRP (+ suitable pad or scrubbing brush). Take up the loosened dirt with a Spray Extractor with hard floor adapter or rubber blade and an absorbent wideheaded mop. Mop the floor with clear water until completely clean.

Stripping: Remove coarse dirt with a sweeping brush or vacuum cleaner. For domestic use, dilute Clean and Strip in a ratio of 1:5 with water. In the commercial sector, use in concentrated form or diluted in a ratio of up to 1:3 (depending on the resistance of the protective film), spraying the floor with clear water before use if necessary. The method of procedure corresponds with that described in the previous paragraph for cleaning after installation, although it may be necessary to allow a standing time of 15-20 minutes.

**Attention:** Do not allow Clean and Strip to dry on the floor. For this reason, work in sections. Before stripping test sensitive floor coverings (e.g., rubber flooring,) check for colour and material fastness at an inconspicuous spot. If necessary, dilute Clean and Strip even more and apply several times using a short standing time. Wear rubber gloves during use and ensure that the rooms to be treated are well ventilated. Do not spray sensitive surfaces (e.g., wood, metal, varnished surfaces) with the cleaning solution.

## Clean and Strip



### 4 CONSUMPTION

Cleaning after installation: 1 l = 10 – 30 m<sup>2</sup>

Stripping: : 1 l = 30-50 m<sup>2</sup> (domestic use) and / or 1 l = 6- 10 m<sup>2</sup> (commercial use, undiluted)

### 5 STORAGE

Clean and Strip should be stored in a cool, dry place in its closed original container. Keep locked up and out of the reach of children.

### 6 TECHNICAL DATA

Data on ingredients (EC recommendation): Less than 5% anionic surfactants, less than 5% non-ionic surfactants, less than 5% NTA, less than 5% phosphates. Other ingredients: Solvents, process materials and aromas.

Product code for cleaning and care products (Giscode): GG 20

pH: approx. 10:0 (concentrate)

ADR/RID: not a dangerous good as defined by transport regulations.

CLP: The product is not classified according to the CLP regulation.

Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

### 7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com)

### 8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage [www.dr-schutz.com](http://www.dr-schutz.com) or on request from the address quoted below.

## Clean and Strip



### Dr. Schutz – We Care About Floors

Headquarter  
Dr. Schutz GmbH  
Holbeinstraße 17  
D-53175 Bonn  
Tel.: +49 (0)228 / 95 35 2-40  
Fax: +49 (0)228 / 95 35 2-46  
E-Mail: [export@dr-schutz.com](mailto:export@dr-schutz.com)  
[www.dr-schutz.com](http://www.dr-schutz.com)

UK  
Dr. Schutz U.K Ltd.  
Unit 24, Anglo Business Park,  
Smeaton Close, Aylesbury Bucks  
HP19 8UP

Contact: Richard Nelson  
Tel.: +44 (0)1296 437827  
Fax: +44 (0)1296 334219  
E-Mail: [richard@dr-schutz.com](mailto:richard@dr-schutz.com)

Ireland  
Dr. Schutz Ireland  
35 Pic Du Jer Park,  
Ballinlough, Cork

Contact: Paul O'Reardon  
Mobile: 0877678388  
E-Mail: [drschutzireland@gmail.com](mailto:drschutzireland@gmail.com)

North America  
Schutz NA  
4701 Bath St 46  
Philadelphia, PA 19137  
USA

Contact: Sam Jamison  
Tel.: +1(877) 272- 4889  
Mobile: +1(215) 510- 7874  
E-Mail: [sam@schutzNA.com](mailto:sam@schutzNA.com)

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.