



## Wood & Cork Floor Polish Mat

### 1 PRODUCT DESCRIPTION

Polymer dispersion containing wax for the initial care treatment of all sealed wood and cork floors treated with a water-resistant satin-finish lacquer. Gives the floor a pleasant matt appearance and protects it against scratches. Regular cleaning of the applied, protective covering is made easier, ideally with Wood & Cork Floor Cleaner

- Now even better matt finish – for a natural look.
- Excellent adhesion, including on UV-sealed ready-made wood floors direct from the manufacturer.
- Complies with the requirements of DIN 18032 for floors in sports areas, gyms, etc.

### 2 AREAS OF APPLICATION

For all wood and cork floors which have been provided with a water-resistant seal

Please pay attention to our technical instructions specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com)

### 3 METHOD OF APPLICATION

Shake Wood & Cork Floor Polish mat well before use. Apply a thin, even film of Wood & Cork Floor Polish mat undiluted to the thoroughly cleaned floor using the Polish Applicator System or a non-felting, wide-headed wiper mop. For increased protection repeat the application at right-angles to the first once the protective film has dried sufficiently to be walked on. Allow the floor surface to dry for at least 12 hours before use but ideally overnight.

The protection of the floor is maintained if Wood & Cork Floor Polish mat is applied at regular intervals after thorough cleaning. The care cycle should be adapted in accordance with the amount of wear and tear to which the floor is subjected and can be taken from the following table:

- Floors subjected to low levels of wear and tear (e.g., in living rooms and bedrooms, offices not open to the public) once or twice per year.
- Floors subjected to medium-to-high levels of wear and tear (e.g., in corridors, on staircases, in offices open to the public) approximately every 3 to 6 months as required, in areas subjected to extreme wear and tear even more frequently
- Floors subjected to medium-to-high levels of wear and tear (e.g., in corridors, on staircases, in offices open to the public) approximately every 3 to 6 months as required, in areas subjected to extreme wear and tear even more frequently.

**Notes:** When applying the product, avoid strong sunlight and drafts. Turn off under-floor central heating before commencing work

### 4 CONSUMPTION

Initial Cleaning/ Refreshing: 20- 25 ml/ m<sup>2</sup> per application

## Wood & Cork Floor Polish Mat



### 5 STORAGE

Store in cool, dry conditions in well sealed receptacles. Store under lock and key and out of the reach of children.

### 6 TECHNICAL DATA

Ingredients: Contains METHYLCHLOROISOTHIAZOLINONE, METHYLISOTHIAZOLINONE, BRONOPOL, perfumes, solvents, care compounds.

pH value : 7,5 – 8,0 (concentrat)

ADR/RID: no dangerous good according ADR

CLP: The product is not classified according to the CLP regulation. EUH208 Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2- methyl-2H-isothiazol-3-one (3:1). May produce an allergic reaction.

Completely emptied canisters can be disposed of in domestic waste or taken to a recycling centre.

### 7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com)

### 8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage [www.dr-schutz.com](http://www.dr-schutz.com) or on request from the address quoted below.

#### Dr. Schutz – We Care About Floors

Headquarter  
Dr. Schutz GmbH  
HolbeinstraÙe 17  
D-53175 Bonn  
Tel.: +49 (0)228 / 95 35 2-40  
Fax: +49 (0)228 / 95 35 2-46  
E-Mail: [export@dr-schutz.com](mailto:export@dr-schutz.com)  
[www.dr-schutz.com](http://www.dr-schutz.com)

UK  
Dr. Schutz U.K Ltd.  
Unit 24, Anglo Business Park,  
Smeaton Close, Aylesbury Bucks  
HP19 8UP

Contact: Richard Nelson  
Tel.: +44 (0)1296 437827  
Fax: +44 (0)1296 334219  
E-Mail: [richard@dr-schutz.com](mailto:richard@dr-schutz.com)

Ireland  
Dr. Schutz Ireland  
35 Pic Du Jer Park,  
Ballinlough, Cork

Contact: Paul O'Reardon  
Mobile: 0877678388  
E-Mail: [drschutzireland@gmail.com](mailto:drschutzireland@gmail.com)

North America  
Schutz NA  
4701 Bath St 46  
Philadelphia, PA 19137  
USA

Contact: Sam Jamison  
Tel.: +1(877) 272- 4889  
Mobile: +1(215) 510- 7874  
E-Mail: [sam@schutzNA.com](mailto:sam@schutzNA.com)

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.