

## H2Oil

### H2Oil white



#### 1 PRODUCT DESCRIPTION

Waterbased careoil on a natural basis.

- For the initial care and refreshing of all oiled wood and cork floors.
- Gives the floor a pleasant satin-matt look.
- Regular cleaning of the refreshed wood or cork floor is made easier with **Dr. Schutz Wood Care**.
- Provides optimal protection.

**H2Oil white** is the white pigmented variant for white oiled floors.

#### 2 AREAS OF APPLICATION

For oiled wood and cork floors with a factory applied or professionally applied finish. Please pay attention to the care instructions specific to the floor.

#### 3 APPLICATION

For post installation cleaning and slightly dirty wood or cork floors, clean beforehand with **Dr. Schutz Wood Care** in combination with a green pad. In the case of very dirty floors or footfall routes, carry out intensive cleaning in advance with **Dr. Schutz Wood Floor Deep Clean**, in a ratio of 1:1 up to 1:3 diluted in water, using a green pad.

After the surface has dried completely, apply initial care, or a refresher coat with **H2Oil**. Before use shake up the **H2Oil** thoroughly. Then apply undiluted with a dry polish applicator, or with a dry, fluff-free wide mop, in a thin, even film on the stripcleaned floor. Allow the area to dry for at least 12 hours before use, or more appropriately overnight.

Please note:

- Avoid strong sunlight and draughts during application.
- Switch off underfloor heating well in advance.
- Rinse the mop used directly after use in clear water, subsequently clean thoroughly with a cleaning solution (e.g. an intensive cleaner).

#### 4 CONSUMPTION

Approx. 20-25 g/m<sup>2</sup> per application, depending on the absorbency of the surface (Range: 40 – 50 m<sup>2</sup>/l).

#### 5 DRYING TIME

12 hours, or overnight.

Low temperatures, increased humidity and poor ventilation can prolong the drying time significantly.

#### 6 STORAGE

Protect against frost. Store in a cool, dry place. Will keep for 24 months in unopened original canister from the date of manufacture. Keep cleaning materials out of the reach of children.

## H2Oil

### H2Oil white



#### 8 TECHNICAL DATA

Contains linseed oil components, perfumes, solvents, care components, CHLOROMETHYLISOTHIAZOLINONE, METHYLISOTHIAZOLINONE, BRONOPOL.

GISCODE: GE10

ADR/RID: not a dangerous good as defined by transport regulations.

CLP: The product is not classified according to the CLP regulation

EUH208 Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7] and 2-methyl-2H-isothiazol-3-one [EC no. 220-239-6] (3:1). May produce an allergic reaction.

EUH210 Safety data sheet available on request.

Even when using low-polluting products, the usual safety measures are to be observed. Keep out of the reach of children. Completely emptied canisters can be disposed of in household waste, or taken to a recycling centre.

#### 9 SPECIAL NOTES

- Cleaning textiles containing the product residues of H2Oil can self-combust during drying in the case of a heat build-up. Therefore wash out cleaning textiles carefully after use, or allow to dry spread out in the open.
- All data given at 23 °C/50% rh/ ventilation. Different conditions may produce different results.

#### 10 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage [www.dr-schutz.com](http://www.dr-schutz.com) or on request from the address quoted below.

#### Dr. Schutz – We Care About Floors

Headquarter  
Dr. Schutz GmbH  
Holbeinstraße 17  
D-53175 Bonn  
Tel.: + 49 228 / 95 35 2-40  
Fax: + 49 228 / 95 35 2-46  
E-Mail: [export@dr-schutz.com](mailto:export@dr-schutz.com)  
[www.dr-schutz.com](http://www.dr-schutz.com)

UK  
Dr. Schutz U.K Ltd.  
Unit 24, Anglo Business Park,  
Smeaton Close, Aylesbury Bucks  
HP19 8UP

Contact: Richard Nelson  
Tel.: 0044 / 1296 437827  
Fax: 0044 / 1296 334219  
E-Mail: [richard@dr-schutz.com](mailto:richard@dr-schutz.com)

Ireland  
Dr. Schutz Ireland  
35 Pic Du Jer Park,  
Ballinlough, Cork

Contact: Paul O'Reardon  
Mobile: 0877678388  
E-Mail: [drschutzireland@gmail.com](mailto:drschutzireland@gmail.com)

North America  
Schutz NA  
4701 Bath St 46, Philadelphia PA  
19137, USA

Contact: Sam Jamison  
Tel.: 001 / 877 272 4889  
Mobile: 001 / 215 510 7874  
E-Mail: [sam@schutzNA.com](mailto:sam@schutzNA.com)

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.