



Floor Shine

1 PRODUCT DESCRIPTION

Shiny polish for both the initial protection of newly-laid/thorough cleaned floors in areas where the application of a hard sealer or a PU sealer is not possible. Also very suitable for the quick refreshment of floor types with a PU factory finish due to the special polymer combination. Ideally suitable for floors in domestic environments. Protects the flooring with an elastic, shiny care film.

- Reduces dirt adhesion and simplifies maintenance care.
- Appropriate for care film renewal in a highspeed process.

2 AREAS OF APPLICATION

Vinyl and linoleum floors. Use on rubber floors is possible only under certain circumstances and should be checked before use.

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

3 METHOD OF APPLICATION

Initial Protection:

Protection of newly-laid/thorough cleaned floors and for the quick refreshment of floor types with a PU factory finish:

For care treatment, apply Floor Shine undiluted with Quickstep or Polish Applicator in an even, thin film to the clean or stripped floor in lengthwise strokes. When the care film is firm enough to walk on, repeat the procedure in the cross direction. In high-demand areas, apply a third coating in lengthwise direction again after drying. Allow the film to dry for at least 12 hours before the floor is walked on. To refresh PU enriched floor coverings, thoroughly clean the floor with Clean and Strip or PU Cleaner before the application of Floor Shine. For this, we recommend using a green pad.

Routine Cleaning:

Dilute Floor Shine in a ratio of 1:100 to 1:200 (100/50 ml to 10 litres of water) and wipe the floor with the solution. Suitable for the removal of lighter surface dirt. For the removal of stronger stains (e. g. in hallways, in front of kitchen ranges) and an ideal cleaning result, we recommend a regular cleaning with PU Cleaner.

Note: Avoid exposure to sunlight and draft during undiluted application, turn off under floor central heating in advance. The coating may powder in some cases if used on old, porous linoleum surfaces which leach due to the application of strongly alkaline cleaning products.



Floor Shine

4 CONSUMPTION

Initial Protection: 2,5-3,5 liters per 100 m²
Daily Cleaning: About 0,2 liters per 100 m²

5 STORAGE

Store in cool, dry conditions in well sealed receptacles. Store under lock and key and out of the reach of children.

6 TECHNICAL DATA

Ingredients: Contains METHYLCHLOROISOTHIAZOLINONE, METHYLISOTHIAZOLINONE, BRONOPOL, perfumes, solvents, care- components.

pH value: 7,5 – 8,0 (concentrate)

ADR/RID: no dangerous good according ADR

CLP The product is not classified according to the CLP regulation. EUH208 Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7] and 2- methyl-2H-isothiazol-3-one [EC no. 220-239-6] (3:1). May produce an allergic reaction.

Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.

Floor Shine



Dr. Schutz – We Care About Floors

Headquarter
Dr. Schutz GmbH
Holbeinstraße 17
D-53175 Bonn
Tel.: +49 (0)228 / 95 35 2-40
Fax: +49 (0)228 / 95 35 2-46
E-Mail: export@dr-schutz.com
www.dr-schutz.com

UK
Dr. Schutz U.K Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP

Contact: Richard Nelson
Tel.: +44 (0)1296 437827
Fax: +44 (0)1296 334219
E-Mail: richard@dr-schutz.com

Ireland
Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork

Contact: Paul O'Reardon
Mobile: 0877678388
E-Mail: drschutzireland@gmail.com

North America
Schutz NA
4701 Bath St 46
Philadelphia, PA 19137
USA

Contact: Sam Jamison
Tel.: +1(877) 272- 4889
Mobile: +1(215) 510- 7874
E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.